

# Rational Active Green Detergent Cleaner Tablets



## Product Usage Guide




### BB179




These instructions are for both Active Green Detergent Tablets (BB179) and Blue Care Tablets (BB177). Please use both products for cleaning your oven.

#### Safety Notes


Allow the oven cabinet to cool before attempting to begin a cleaning cycle. Never open the oven door during the cleaning cycle.



**1** Use appropriate PPE as indicated in the Safety Data Sheet.



**2** Remove grids and clear food debris. Slide racks to one side.



**3** Select a cleaning cycle.


The CareControl screen will then display the number of packets of detergent and Care Tablets to use for the cleaning cycle selected. It will also show a reminder of where the tablets should be placed.

#### Health & Safety


Please refer to relevant COSHH Safety Data Sheet




Scan for further product details




**4** Lift up and twist the side rack out of the way of the fan. Remove the foil from the Green Detergent Tablets (**BB179**)



**5** Place the detergent tablets inside the basket located inside the fan. Twist the side rack back into position.



**6** Open the foil packet of Blue Care Tablets (**BB177**) and tip them into the blue drawer on the front of the unit and then close the drawer.



**7** Begin the cleaning cycle, simply close the oven door and the unit will automatically begin cleaning. Once the cleaning cycle has completed, your SelfCookingCentre® will go into standby mode.

After the clean cycle check for detergent residue. Wake your oven by tapping on the control panel or opening the oven door. The oven cabinet will illuminate, allowing you to check for any detergent residue that may have been left over after the cleaning cycle. In this case, while wearing gloves, simply wipe with a clean cloth to remove the residue and then rinse using the hand shower.